



- NOTE 1 ONLY 1 LOG UNIT TO BE CONNECTED TO MILES COUNTER ELSE TWICE DISTANCE WILL BE RECORDED
- NOTE 2 EITHER A WINDSPEED ONLY MASTHEAD UNIT OR THE O/P FROM A WIND MONITOR OR WIND ANGLE MAY BE CONNECTED TO NAV 2, BUT NOT BOTH
- NOTE 3 4 UNITS MAY BE RUN FROM 1 PADDLE WHEEL TRANSDUCER
- NOTE 4 EITHER A SYSTEM MAY BE RUN FROM A CONTROL BOX OR DIRECTLY FROM THE SHIP'S BATTERY BUT NOT BOTH, 2 ALTERNATIVES SHOWN FOR COMPLETENESS.
- NOTE 5 TRAIL AND PADDLE TRANSDUCERS ARE NOT DIRECTLY INTERCHANGEABLE.

STOWE MARINE EQUIPMENT LIMITED
 INSTALLATION DRAWING (NAVIGATOR RANGE) ISS 1 NOV '84